



Workstation Specialists

WWW.WORKSTATIONSPECIALISTS.COM



THANK YOU FOR
PURCHASING YOUR
SYSTEM FROM
WORKSTATION
SPECIALIST.

TO RECIEVE A LOYALTY
DISCOUNT PLEASE
QUOTE PROMO CODE:

RPT-CSTM

CONTACT SUPPORT

FREE PHONE:
+44 0800 180 4801

EMAIL:
SUPPORT@WKSMAIL.COM




WORKSTATION
QUICK START GUIDE

QUICK START GUIDE


IMAGES ARE FOR ILLUSTRATION PURPOSES ONLY. SYSTEM LAYOUTS MAY VARY.

V1.2

KEY




STEP 1 - DISPLAY




INSERT THE APPROPRIATE VIDEO OUTPUT CABLE TO THE DISPLAY OUTPUT LOCATED IN THE LOWER HALF OF YOUR WORKSTATION. (PLEASE BE AWARE ANY DEACTIVATED DISPLAY PORTS WILL BE DENOTED BY A LABEL). INSERT THE CORRESPONDING END TO YOUR MONITOR. IF REQUIRED DISPLAY CABLE ADAPTORS ARE SUPPLIED WITH YOUR WORKSTATION. CONVERTERS SHOULD BE CONNECTED AT THE WORKSTATION END OF THE CABLE.

STEP 2 - KEYBOARD, MOUSE & NETWORK




INSERT THE 2 USB CABLES FROM YOUR KEYBOARD AND MOUSE (OR THE PROVIDE WIRELESS KEYBOARD AND MOUSE DONGLE) INTO AVAILABLE USB PORTS LOCATED ON THE COMPUTER WORKSTATION I/O. IF USING A CABLED NETWORK CONNECTION PLUG IN YOUR ETHERNET CABLE TO AN AVAILABLE ETHERNET PORT.

STEP 3 - POWER




SWITCH THE MASTER POWER SWITCH TO OFF (POSITION 0). INSERT THE POWER CABLE SUPPLIED WITH YOUR SYSTEM. CONNECT THE OTHER END TO AN AVAILABLE MAINS POWER SOCKET. SWITCH THE MASTER POWER SWITCH ON (POSITION 1).

STEP 4 - START SYSTEM



LOCATE AND PRESS THE POWER BUTTON ON THE FRONT OF YOUR WORKSTATION AND MONITOR TO TURN ON YOUR SYSTEM. TO GET GRAPHICAL DISPLAY YOUR MONITOR SOURCE SETTINGS MAY NEED TO BE ALTERED.

STEP 5 - ACTIVATE WINDOWS



FOLLOW THE ON-SCREEN WINDOWS SETUP WIZARD. WHEN ASKED FOR YOUR WINDOWS ACTIVATION LICENSE ENTER THE LICENSE KEY LOCATED ON THE SIDE OF YOUR SYSTEM.

*PLEASE ENSURE ALL SYSTEM AIR INTAKES AND VENTS ARE FREE FROM OBSTRUCTION.